





## BLISSBUDS NOIR VIRELESS EARBUDS

BlissBuds Noir

## Un-boxing the device Pebble BlissBuds Noir


- Charging Case Type-C Charging Cable
- Warranty Card
- Specifications

### Model Name

Model No PTWE204 Play Time Up to 25 hours (@50% Volume) Bluetooth V5.4 Charging Time Up to 1.5 hours Working Range Up to 10m

Type-C Charging Port Driver Size 13mm Dynamic Frequency Response 300~3.2kHz

# How to Operate



## Please fully charge the Earbuds and the charging case before your first use.

- 2.Use the included USB-C charging cable.

Operation

### LED Light Display

Earbuds Power On	The case white light will turn on for 5 seconds and then go out when open the charging case cover.	
Earbuds Power Off	The case white light will on for 5 seconds and then go out when put the earbuds in the case and close the lid	
Pairing mode	/	
Get paired	Voice prompt "dong dong dong"	
Earbuds charging in the case	Put the earbuds in the case, close the cover and charge. The case white light will on for 5 seconds and then go out	
Earbuds fully charged in charging case	/	
Charging case charged by USB-C cable	The orange light always on	
Fully charged by USB-C cable	The white light always on.	
Earbuds Low battery	Voice prompt " du du du"	
Power On/Off		

LED Display

## The earbuds will automatically power on when you open the charging case cover and power off when you close it.

automatically as well.

- 2.To manually power on, tap and hold for 4 seconds L/R . To manually power off, tap and hold the button for 4 seconds under disconnected mode.
- Automatic power off: The earbuds will turn off automatically after 3 minutes if they have not paired with any device via Bluetooth. When in low battery, they will power off
- Bluetooth Pairing with your Device

## 1. Open the case and take out the earbud.

2.Then select 'PBL Blissbuds Noir' from your device's Bluetooth list to get paired. You will hear a 'dong dong dong' sound when connected successfully.

### Mono Listening After pairing with th e device successfully, you can take either of them out of the charging case for the mono

listening experience

Tap and Hold for 4 Seconds

(L/R) Turn On Manually (L/R) Turn Off Manually Tap and Hold for 4 Second Under Disconnect Mode (L/R) Play/Pause

(L)	Previous Track	Tap and hold L for 2 seconds
(R)	Next Track	Tap and hold R for 2 seconds
(R)	Volume +	Tap twice till max volume by reminding "didi"
(L)	Volume -	Tap Twice
(L/R)	Answer/End a Phone Call	Tap Twice
(L/R)	Reject a Phone Call	Hold down for 2 seconds
(L)	Activate Voice Assistant	Tap Four Times
(L/R)	ANC ON I Transparency I ANC OFF	Triple Click Left or Right to Transparency on - ANC on - ANC off
Safety Precautions		
.Do not expose earbuds to extreme temperatures.		

- 2.Do not modify the product. Doing so voids the warranty and may cause injury or malfunction. 3.Do not immerse in water.
- 4.Clean the earbuds with a mild antiseptic. Avoid using alcohol-based disinfectants. 5.Keep connectors clean to maintain audio quality.
- 6.Set volume to minimum before use, then adjust gradually.
- 7.Stop using if you experience irritation, rash, discharge, or discomfort. Avoid use in situations where you must hear your surroundings (e.g., driving, cycling).



- Caution
- Replacing the charging case or earbuds with incompatible parts can disable safety features.



- Do not dispose of batteries in fire or expose them to high heat.
- Avoid crushing or cutting the battery.
- · Storing in high temperatures may cause explosion or leakage

Hi There

Thank you for choosing Pebble! You are now the proud owner of BlissBuds Noir Wireless Earb

**Thank You** 

For your ears, let BlissBuds Noir spread the magic in your ears. These **BlissBuds Noir** is a genuine high-que product that comes with 1 year Warranty. quality Pebble

- ere's a lot you can do when you have a free hand, use it we

- For Availing Warranty
  - Contact us at- https://www.pe and Retail Outlets near you Call on +91 8800271651 or email at support@pebblecart.com

Scan & register your product for 1 Year Warranty