



pebble



CYCLO BUDS

WIRELESS EARBUDS

Un-boxing the device

- Pebble Cyclo Buds
- Charging Case
- Type-C Charging Cable
- Warranty Card

Specifications

Model Name	Cyclo Buds
Model No	PTWE203
Play Time	Up to 20 hours (@50% Volume)
Bluetooth	V5.4
Charging Time	Up to 1.5 hours
Working Range	Up to 10m
Charging Port	Type-C
Driver Size	10mm Dynamic
Frequency Response	300~3.2kHz

How to Operate



Charging

1. Please fully charge the Earbuds and the charging case before your first use.
2. Use the included USB-C charging cable.

LED Light Display

Operation	LED Display
Earbuds Power On	Blue light for 1 second, into the white and blue alternate
Earbuds Power Off	The light off
Pairing mode	White & blue Lights flash alternately
Get paired	Light off and voice prompt "dong dong dong"
Earbuds charging in the case	Earbuds white light always on
Earbuds fully charged in charging case	The light off
Charging case charged by USB-C cable	Green light blinks
Fully charged by USB-C cable	Green light always on
Earbuds Low battery	Voice prompt " du du du" every 60 seconds

Power On/Off

1. The earbuds will automatically power on when you open the charging case cover and power off when you close it.
2. To manually power on, tap and hold for 4 seconds L/R . To manually power off, tap and hold the button for 4 seconds under disconnected mode.
3. Automatic power off: The earbuds will turn off automatically after 5 minutes if they have not paired with any device via Bluetooth. When in low battery, they will power off automatically as well.

Bluetooth Pairing with your Device

1. Open the case, both earbuds flash blue then the earbuds flashes white & blue alternately.
2. Then select 'PBL Cyclo Buds' from your device's Bluetooth list to get paired. A 'dong dong dong' sound will play when connected successfully

Mono Listening

After pairing with the device successfully, you can take either of them out of the charging case for the mono listening experience.

Operation Function of Earbuds MDF

(L/R)	Turn On Manually	Tap and Hold for 4 Seconds
(L/R)	Turn Off Manually	Tap and Hold for 4 Seconds Under Disconnect Mode
(L/R)	Play/Pause	Tap Once
(L)	Previous Track	Tap and hold L for 2 seconds
(R)	Next Track	Tap and hold R for 2 seconds
(R)	Volume +	Tap twice till max volume by reminding "didi"
(L)	Volume -	Tap Twice
(L/R)	Answer/End a Phone Call	Tap Twice
(L/R)	Reject a Phone Call	Hold down for 2 seconds
(L)	Activate Voice Assistant	Tap Four Times
(R)	Gaming mode	Tap four times right side to enter "Game Mode" - four times to enter "Music Mode"

Safety Precautions

1. Do not expose earbuds to extreme temperatures.
2. Do not modify the product. Doing so voids the warranty and may cause injury or malfunction.
3. Do not immerse in water.
4. Clean the earbuds with a mild antiseptic. Avoid using alcohol-based disinfectants.
5. Keep connectors clean to maintain audio quality.
6. Set volume to minimum before use, then adjust gradually.
7. Stop using if you experience irritation, rash, discharge, or discomfort.
8. Avoid using the earbuds in situations where you need to hear your surroundings (e.g., while driving or cycling).

Caution 

- Replacing the charging case or earbuds with incompatible parts can disable safety features.
- Do not dispose of batteries in fire or expose them to high heat.
- Avoid crushing or cutting the battery.
- Storing in high temperatures may cause an explosion or leakage.

Thank You

Hi There

Thank you for choosing **Pebble!**

You are now the proud owner of **Cyclo Buds** Wireless Earbuds.

There's a lot you can do when you have a free hand, use it well.

For your ears, let **Cyclo Buds** spread the magic in your ears.

These **Cyclo Buds** is a genuine high-quality Pebble

product that comes with 1 year Warranty.

For Availing Warranty

- Contact us at- <https://www.pebblecart.com/page/raise-a-complaint> and Retail Outlets near you
- Call on +91 8800271651 or email at support@pebblecart.com



Scan & register your product for
1 Year Warranty