pebble

User Manual



ESCAPE NEO

WIRELESS HEADPHONES


Un-boxing the device

- Escape Neo Wireless Headphones
- Charging Cable
- Type-C Charging Cable
- Warranty Card

Specifications

Model Name	Pebble Escape Neo
Model No	PWH06
Play Time	Up to 50 hours (@50% Volume)
Bluetooth	V6.0
Working Range	Up to 10m
Charging Port	Type-C
Driver Size	40mm
Water Resistant	IPX4

How to Operate



1. ⊙ : MFB
2. ＋ : Volume Up/Next song
3. － : Volume down/Previous song
4. ⏻ : Power on/off,Music play/pause/call
5. Bluetooth indicator
6. Type-C charging port
7. 3.5mm jack
8. Call Microphone Hole


Operating Instructions

1. **Power on** : Press and hold "⏻" for 3 seconds: The white light will stay on for 1 second, then the headset will power on. At this point, it will enter pairing mode or reconnect to the last paired Bluetooth device.

2. **Power off**: Press and hold "⏻" for 3seconds: The white light will stay on for 3 second, then the headset will power off.

3. **Pairing**: Press and hold the power button for 3 seconds to enter pairing mode; Turn on Bluetooth on your phone (computer, iPad, etc.), search for the Bluetooth device named **PBL Escape Neo**, then tap the device name to connect.





Music play

1. Volume up: Click the "+" button to increase volume
2. Volume down: Click the "-" button to decrease volume
3. Next song: Press and hold the "+" button around 1 second
4. Previous song: Press and hold the "-" button around 1 second
5. Music play/pause: Click the "⏻" button

Calling (Phone)

1. **Answer call**: Click the "⏻" button when call is coming
2. **End call**: Click the "⏻" button when call is over
3. **Cancel call**: Click the "⏻" button when calling
4. **Reject call**: Press and hold the "⏻" button around 2 seconds when call is coming

Reset


Press the Volume "+" and Volume "-" buttons at the same time to clear the headphone pairing history

Siri or Google Assistant

Press and hold the "⏻" button around 2 seconds to activate Siri or Google Assistant.

EQ Mode Switch

Doubble-click the "⊙" button to cycle through the three EQ modes Jazz Mode/Gaming Mode/Music Mode



Light Indicator


The connection was successful	Light Off
Pairing Status	White light flashing
Clear Pairing	White light flashing
Listen to Music	Light Off
Fully charged	Light Off
Power Off	The white light flashes for 3 seconds and then goes out
Charging	The red light is always on

Line-in Mode

Insert the audio cable into the 3.5mm audio port of the headphone, and you can directly connect it to a playback device for music listening. The headphone will be in Line-in mode at this time.

Note: The headphone will be power off once plug the 3.5mm audio cable into audio jack (When headphone is power on), the 3.5mm audio cable must be taken out from the headphone if need to turnon the headphone.

Charging Indicator



Q&A

1. Headphone won't power on
   Please check if the headphone has remaining battery.
2. Bluetooth pairing fails
   Ensure the headphone are powered on and in pairing mode, keep within 1 meter during pairing, then then power the headphone off and on again to re-pair.
3. Auto-reconnection
   After powering on, the headphone will automatically reconnect to the last paired phone.
4. Audio cutting out / stuttering
   Check if the connection distance exceeds the effective range, and ensure there are no obstacles between the device and the headphone.
5. Charging method
   Use a charger, car charger, or power bank with a DC output of 5V/1A.

Safety Precaution

1. Do not expose headphones to extreme temperatures.
2. Do not modify the product. Doing so voids the warranty and may cause injury or malfunction.
3. Do not immerse in water.
4. Clean the headphones with a mild antiseptic. Avoid using alcohol-based disinfectants.
5. Keep connectors clean to maintain audio quality.
6. Set volume to minimum before use, then adjust gradually.
7. Stop using if you experience irritation, rash, discharge, or discomfort.
8. Avoid use in situations where you must hear your surroundings (e.g., driving, cycling).

Caution

- Replacing the charging case or headphones with incompatible parts can disable safety features.
- Do not dispose of batteries in fire or expose them to high heat.
- Avoid crushing or cutting the battery.
- Storing in high temperatures may cause explosion or leakage.

Thank You

Hi There

Thank you for choosing **Pebble!**

You are now the proud owner of **Pebble Escape Neo** Wireless Headphones.

There's a lot you can do when your hands are free—use them well! Let **Pebble Escape Neo** bring magic to your world of sound.

These **Pebble Escape Neo** are a genuine high-quality Pebble product that come with 1 Year Warranty.

For Availing Warranty

Contact us at- https://support.pebblecart.com/support/tickets/new and Service Centres near you.

Call on +91 8800271651 or
email at support@pebblecart.com

Scan & register your product for 1 Year Warranty