



User Manual



Glide 20

STEREO SOUNDBAR
20W Deep Bass Output

Signature Sound.
Anytime, Anywhere.

LED Light Modes

Blink Blue Light only	Soundbar is Power ON (in pairing mode) but not connected with any device
Blue Lights Glow	When Connected with device
Blink Blue Light	When Playing Song
Blink Blue Light	When get a Call
Glow Red Light	When connected to Charging
OFF Red Light	When Charged 100% and still connected to charging
Blink Blue LED for 2 Seconds only	When Switch between Mode

Functional Buttons

To Turn ON or OFF the Speaker, please use the slider button located on the back of the speaker.

Place the Soundbar close to (within 10 metres of) your Bluetooth-enabled device. If not in Bluetooth mode, short press the Mode button to switch to Bluetooth mode. Enable Bluetooth on your smartphone, tablet, or media player. Navigate to the Bluetooth settings menu and search for new devices. The Bluetooth name for this Soundbar is "Glide 20"

Un-boxing the device

- Pebble Glide 20 Stereo Soundbar
- Type-C Charging Cable
- User Manual

Specifications

Model Name	Pebble Glide 20
Model No.	PBS202
Bluetooth	V5.4
Playtime	Up to 6 Hrs (@ 50%)
Power Output	20W
Speaker Driver Size	52mm ± 1mm
Impedence	3.2 Ohm ± 7%
Working Range	Up to 10m
Charging Type	Type-C Port
Connectivity	USB/AUX/TF/BT

TWS Function

Before entering TWS mode, make sure both Soundbar are powered on and should be in Bluetooth mode, none of them should be connected to the mobile phone or any other devices. In any one Soundbar double press the Ⓜ button, you will hear the sound which means that the two Soundbar begin to enter the paired state. After connection, both Soundbar will automatically pair and play at the same time.

Charging

Connect the small end of the Type C charging cable (included) to the Type-C port located on the back of the Soundbar. Connect the larger end of the cable to your computer's USB port or an AC adaptor(not included).The LED indicator will turn red while charging. Once fully charged, the red LED will turn off.

Notice for Use

1. For the first use, please charge the battery first. Do not play music while charging.
2. Please use DC 5V cable for charging.

Functionality



Music Functionality	Button Function
Next Song	Long press ⏭ for next track
Previous Song	Long press ⏮ for Previous Song
Volume Up	Volume ⏩ Short Press
Volume Down	Volume ⏪ Short Press
Play	Short press ⏮ Button
Pause	Short press ⏮ Button again
RGB LED working	Long press ⏮ for LED Change
Answer Call	Short press Ⓜ Button to answer the phone call
End ongoing Call	Short Press Ⓜ Button Once
Reject Call	Double Press Ⓜ Button
Redial	Double Press Ⓜ Button when in stable state

3. When music is played, if the sound is intermittent, it may be lack of power, please charge it firstly.
4. Activate the Bluetooth feature on the phone, laptops or tablets, and set the device to search for wireless device.


Safety Information

- Do not expose the battery to excessive heat such as sunlight.
- Do not use this product in the water.
- Do not dispose of the device in a fire because this will result in an explosion.
- Do not expose the device to contact with sharp objects as this will cause scratches and damage.
- Do not let the device fall on the floor. The internal circuit might get damaged
- Only use attachments/accessories specified by the manufacturer.

Google Assistance	Double Press Ⓜ Button for Once
Stand by Mode	Auto off after 10 min if BT are not connected.
Switch Between Bluetooth/USB /TF-Card	Short Press Ⓜ Button for Once
Long Press the Play & Pause button for 2 seconds	Go in TWS mode (if there are two speakers)
TWS Connected	Long press Ⓜ Button for 2 seconds
TWS Disconnected	Long press Ⓜ Button for 2 seconds
TWS Pairing	Long press Ⓜ Button for 2 seconds

Soundbar Back

1. Power ON/OFF
2. AUX IN
3. USB
4. TF Card
5. DC IN



Thank You

Hi There

Thank you for choosing **Pebble!**

You are now the proud owner of **Pebble Glide 20 Bluetooth Soundbar**

The Wireless Soundbar is crafted to give you a great listening experience. It is not just a Soundbar, but a way of living and a lifestyle statement. Now enjoy the highs & lows with complete clarity.

This **Pebble Glide 20** is a genuine high-quality **Pebble** product that comes with a **1 Year Warranty**

For Availing Warranty

- Contact us at- <https://www.pebblecart.com/pages/raise-a-complaint> and Retail Outlets near you
- Call on +91 8800271651 or email at support@pebblecart.com



Scan & register your product for
1 Year Warranty