



Light Up Every Beat.

PHOTON
WIRELESS SPEAKER

User Manual


Un-boxing the Device

- Photon Wireless Speaker
- Type-C Charging Cable
- User Manual

Specifications

Model Name	Pebble Photon
Model No	PBS113
Speaker Output	16W
Play Time	Up to 3 hours (@50% Volume)
Bluetooth	V5.3
Working Range	Up to 10m
Charging Type	Type-C Charging
Battery	2400mAh

How to Operate



(1) Mode Button

Short press to switch between available modes: BT / USB / TF (microSD) /AUX.

(2) On/Off/Volume Button

Long press the button to turn the speaker on or off. Pairing name: **PBL Photon**

Play/Pause Button

Short press to pause or play the music.

(3) +Volume Up/Next Track Button

Long press to increase the volume. Short press to change to the next track.

(4) Light mode

Short press to switch between different lighting modes.

(5) -Volume Down/Previous Track Button

Long press to decrease the volume. Short press to change to the previous track.

(6) USB Port

Insert U disk to play compatible audio.

(7) AUX Port

Insert AUX device to play compatible audio.

(8) MicroSD Card Port

Insert microSD card to play compatible audio.

(6) Charging Port

Turn off the unit before charging. Connect the small end of the Type-C charging cable (included) to the Type-C port and connect the larger end of the cable to your computer's USB port or an AC adaptor (not included) to charge the speaker. The red light will be on while charging. Once it is fully charged the red light will be off.

The charging indicator will remain red while charging and turn off when fully charged. Do not overcharge.

Do not overcharge.

Note:

Only MP3 format files are compatible. Maximum size of the USB/ micro SD device that can be connected is 32GB.

DO'S AND DON'TS

Do not play music at excessive levels as damage to hearing and/or equipment may result. Do not use outdoors in wet or in damp surroundings.

Safety Precaution

- Do not expose the battery to excessive heat such as sunlight.
- Do not use this product in the water.
- Do not dispose of the device in a fire because this will result in an explosion.
- Do not expose the device to contact with sharp objects as this will cause scratches and damage.
- Do not let the device fall on the floor. The internal circuit might get damaged
- Only use attachments/accessories specified by the manufacturer

Thank You

Hi There

Thank you for choosing **Pebble!**

You are now the proud owner of **Pebble Photon** Wireless Speaker

The Wireless Speaker is crafted to give you a great listening experience. It is not just a speaker, but a way of living and a lifestyle statement. Now enjoy the highs & lows with complete clarity.

This **Pebble Photon** is a genuine high-quality Pebble product that comes with **1 Year Warranty**.

For Availing Warranty

- Contact us at- <https://www.pebblecart.com/page/raise-a-complaint> and Retail Outlets near you
- Call on +91 8800271651 or email at support@pebblecart.com



Scan & register your product for 1 Year Warranty