



pebble



STRIKER BUDS

WIRELESS EARBUDS


Un-boxing the device

- Pebble Striker Buds
- Charging Case
- Type-C Charging Cable
- Warranty Card

Specifications

Model Name	Striker Buds
Model No	PTWE01
Play Time	Up to 40 hours (@50% Volume)
Bluetooth	V5.4
Charging Time	Up to 2 hours
Working Range	Up to 10m
Charging Port	Type-C
Driver Size	13mm Dynamic
Water Resistant	IPX4

How to Operate



Charging

1. Fully charge the earbuds and charging case before first use.
2. Use the included USB-C charging cable.

LED Light

Operation	LED
Earbuds Power On	Flash red & blue
Earbuds Power Off	Flash red 3 times then light off
Pairing mode	Red and blue light of the main earbud keep flashing alternately
Get paired	Light off and voice prompt "dong dong"
Earbuds charging in the case	Keep red light
Earbuds fully charged in charging case	Red light off
Charging case charged by USB-C cable	RGB flash alternately
Fully charged by USB-C cable	RGB Remain blue
Earbuds Low battery	RGB flash quickly

Power On/Off

1. The earbuds will automatically power on when you open the charging case cover and power off when you close it
2. To manually power off, tap and hold the button for 4 seconds while disconnected.

Note: In music mode, manual power off is disabled to avoid accidental touches.
3. Automatic power off: The earbuds will turn off automatically after 300 seconds if they have not paired with any device via Bluetooth. When in low battery, they will power off automatically as well.

Bluetooth Pairing with your Device

1. Open the case, both earbuds flash blue then the master earbud flashes red & blue alternately, slave earbud lights off.
2. Then select 'PBL Striker Buds' from your device's Bluetooth list to get paired. A 'dong dong' sound indicates a successful connection.

Operation Function of Earbuds MDF

(L/R)	Turn On Manually	Tap and Hold for 4 Seconds
(L/R)	Turn Off Manually	Tap and Hold for 4 Seconds Under Disconnect Mode
(L/R)	Play/Pause	Tap Once
(L)	Previous Track	Tap Twice
(R)	Next Track	Tap Twice
(R)	Volume +	Tap and Hold for 2 Seconds Till Max Volume by Reminding "Dong"
(L)	Volume -	Tap and Hold for 2 Seconds
(L/R)	Answer/End a Phone Call	Tap Twice
(L/R)	Reject a Phone Call	Tap and Hold for 2 Seconds
(L)	Activate Voice Assistant	Tap Four Times
(R)	Gaming Mode	Tap four Times to Enter "Game Mode" - four Times to Enter "Music Mode"
(L/R)	Reset	Tap 5 Times

Safety Precaution

1. Do not expose earbuds to extreme temperatures.
2. Do not modify the product. Doing so voids the warranty and may cause injury or malfunction.
3. Do not immerse in water.
4. Clean the earbuds with a mild antiseptic. Avoid using alcohol-based disinfectants.
5. Keep connectors clean to maintain audio quality.
6. Set volume to minimum before use, then adjust gradually.
7. Stop using if you experience irritation, rash, discharge, or discomfort.
8. Avoid use in situations where you must hear your surroundings (e.g., driving, cycling).

Caution



- Replacing the charging case or earbuds with incompatible parts can disable safety features.
- Do not dispose of batteries in fire or expose them to high heat.
- Avoid crushing or cutting the battery.
- Storing in high temperatures may cause explosion or leakage.

Thank You

Hi There

Thank you for choosing **Pebble**!You are now the proud owner of **Striker Buds** Wireless Earbuds.

There's a lot you can do when you have a free hand, use it well.

For your ears, let **Striker Buds** spread the magic in your ears.These **Striker Buds** is a genuine high-quality Pebble

product that comes with 1 year Warranty.

For Availing Warranty

- Contact us at- <https://www.pebblecart.com/page/raise-a-complaint> and Retail Outlets near you
- Call on +91 8800271651 or email at support@pebblecart.com



Scan & register your product for 1 Year Warranty